

FUEL INJECTION (FUEL SYSTEMS)(STI) > Fuel Filter

REMOVAL

WARNING:



Place "NO OPEN FLAMES" signs near the working area.


CAUTION:

- Be careful not to spill fuel.
- If the fuel gauge indicates that two thirds or more of the fuel is remaining, be sure to drain fuel before starting work to avoid the fuel to spill.
- Be careful not to drop or apply any impact to the fuel pump during work. This may deteriorate its performance.

NOTE:

The fuel filter is built in fuel pump assembly.

1. Remove the fuel pump assembly. 
2. Remove the fuel level sensor. 
3. Disconnect the pump assembly connector from sub tank bracket assembly.




4. Cut off the tab holders connecting the sub tank bracket assembly and the sub tank in four locations, and separate the two.

CAUTION:


Be careful not to damage the sub tank.

NOTE:

If the O-ring is remaining on the sub tank, remove.




5. Disconnect two connectors of fuel delivery pipe from fuel filter assembly.




6. Push to compress the fuel filter assembly in the direction of the arrow, remove clip (A), and separate the sub tank bracket assembly and the fuel filter assembly.

CAUTION:

When separating the sub tank bracket assembly and the fuel filter assembly, be careful not to damage the ground wire.




7. Disconnect the connector from the pump assembly.



8. Lift the two tab holders connecting the pump assembly to the fuel filter using a flat tip screwdriver (with a shaft diameter of approx. 3 mm (0.12 in)), etc., and separate the fuel filter and pump assembly.

CAUTION:

- To prevent damaging the tabs of the pump assembly, wrap the tip of flat tip screwdriver (A), etc. with tape (B).



- **Be careful not to drop or apply any impact to the pump assembly.**

NOTE:

If the spacer and O-ring is remaining on the pump assembly, remove these.

