


7. Control Module I/O Signal



G2M1012

Content	Con- nector No.	Ter- minal No.	Signal (V)			Note	
			lg SW		Engine ON (Idling)		
			OFF	ON (Engine OFF)			
Crankshaft position sensor	Signal (+)	B95	4	—	0	*	*Sensor output waveform
	Signal (-)	B95	5	—	0	0	
	Shield	B95	6	—	0	0	
Camshaft position sensor	Signal (+)	B96	1	—	0	*	*Sensor output waveform
	Signal (-)	B96	2	—	0	0	
	Shield	B96	3	—	0	0	
Mass air flow sensor	Power supply	B43	8	—	10 — 13	13 — 14	—
	Signal	B43	9	—	0 — 0.3	0.8 — 1.2	—
	GND	B43	10	—	0	0	—
Throttle position sensor	Signal	B95	2	—	Fully closed: 4.7 Fully opened: 0.9	Fully closed: 4.7 Fully opened: 0.9	—
	Power supply	B95	3	—	5	5	—
	GND	B95	1	—	0	0	—
Oxygen sensor	Signal	B43	6	—	0.6	Rich mixture: 0.7 — 1.0 Lean mixture: 0 — 0.2	—
	Shield	B43	17	—	0	0	—
Knock sensor	Signal	B96	5	—	3 — 4	3 — 4	—
	Shield	B96	4	—	0	0	—
Engine coolant temperature sensor	B43	7	0	—	0.7 — 1.5	0.7 — 1.5	*After warm-up
Vehicle speed sensor 2	B95	11	—	—	0 or 5	0 or 5	"5" and "0" are repeatedly displayed when vehicle is driven.
Pressure sensor	Signal	B43	4	—	2.4 ↔ 2.7	1.4 — 1.6	—
	Power supply	B43	3	—	5	5	—
	GND	B43	21	—	0	0	—
Idle switch	B96	6	—	—	ON:0, OFF:5	ON:0, OFF:5	—
Starter switch	B96	10	—	—	0	0	Cranking: 10 to 14
Air conditioner switch	B96	9	—	—	ON:10 — 13, OFF:0	ON:13 — 14, OFF:0	—
Ignition switch	B95	12	0	—	10 — 13	13 — 14	—


7. Control Module I/O Signal

Content	Con- nector No.	Ter- minal No.	Signal (V)			Note	
			Ig SW		Engine ON (Idling)		
			OFF	ON (Engine OFF)			
Neutral position switch	B95	10	—	N Position: 7 Other: 0	N Position: 7 Other: 0	—	
Test mode connector	B96	13	—	7	7	When connected: 0	
Read memory connector	B96	12	—	7	7	When connected: 0	
Back-up power supply	B43	15	10 — 13	10 — 13	13 — 14	—	
Control module power supply	B43	2	0	10 — 13	13 — 14	—	
	B43	13	0	10 — 13	13 — 14	—	
Ignition control	#1	B44	10	—	0	—	—
	#2	B44	9	—	0	—	—
	#3	B44	8	—	0	—	—
	#4	B44	7	—	0	—	—
Fuel injector	#1	B44	13	10 — 13	10 — 13	13 — 14	—
	#2	B44	12	10 — 13	10 — 13	13 — 14	—
	#3	B44	11	10 — 13	10 — 13	13 — 14	—
	#4	B44	26	10 — 13	10 — 13	13 — 14	—
Idle air control solenoid valve	OPEN end	B44	2	—	8 — 9	9 — 10	—
	CLOSE end	B44	1	—	6 — 7	6 — 7	—
Fuel pump relay control	B44	23	—	ON: 0 OFF: 10 — 13	0	—	
Air conditioner cut relay control	B44	22	—	ON: 0 OFF: 10 — 13	ON: 0 OFF: 13 — 14	—	
Radiator fan 1 control	B44	17	—	ON: 0 OFF: 10 — 13	ON: 0 OFF: 13 — 14	—	
Radiator fan 2 control	B44	4	—	ON: 0 OFF: 10 — 13	ON: 0 OFF: 13 — 14	—	
Self-shutoff control	B44	5	—	10 — 13	13 — 14	—	
Wastegate control	B44	3	—	10 — 13	13 — 14	—	
Malfunction indicator lamp	B44	19	—	1, max.	—	Light "ON": 1, max. Light "OFF": 10 — 14	
Pressure exchange solenoid valve	B44	20	—	ON: 0 OFF: 10 — 13	ON: 0 OFF: 13 — 14	—	
Engine tachometer output	B96	16	—	—	—	—	
Purge control solenoid valve	B44	6	—	ON: 0 OFF: 10 — 13	ON: 0 OFF: 13 — 14	—	
GND (sensors)	B43	21	—	0	0	—	
GND (injectors)	B44	24	—	0	0	—	
	B44	25	—	0	0	—	
Ignition system	B44	15	—	0	0	—	
GND (power supply)	B44	14	—	0	0	—	
GND (control systems)	B43	11	—	0	0	—	
	B43	22	—	0	0	—	
Select Monitor Signal	B96	8	—	—	—	—	
	B96	7	—	—	—	—	


8. Diagnostics Chart for Engine Starting Failure


A: BASIC DIAGNOSTICS CHART

When engine cranks but does not start, perform diagnostics in accordance with the following chart.



B: CONTROL UNIT POWER SUPPLY AND GROUND LINE






1. CHECK MAIN RELAY.

- 1) Turn the ignition switch to OFF.
- 2) Remove main relay.
- 3) Connect battery to main relay terminals No. 1 and No. 2.
- 4) Measure resistance between main relay terminals.

Terminals / Specified resistance:

No. 3 — No. 5 / 10 Ω, max.

No. 4 — No. 6 / 10 Ω, max.



2. CHECK POWER SUPPLY CIRCUIT OF ECM.

- 1) Install main relay.
- 2) Turn ignition switch to ON.
- 3) Measure power supply voltage between ECM connector terminals and body.

Connector & terminal / Specified voltage:

(B43) No. 12 — Body / 10 V, min.

(B43) No. 13 — Body / 10 V, min.

(B43) No. 15 — Body / 10 V, min.

(B95) No. 12 — Body / 10 V, min.

3. CHECK GROUND CIRCUIT OF ECM.

- 1) Turn ignition switch to OFF.
- 2) Measure resistance of harness connector between ECM and body.

Connector & terminal / Specified resistance:

(B43) No. 11 — Body / 10 Ω, max.


(B43) No. 22 — Body / 10 Ω, max.

(B44) No. 14 — Body / 10 Ω, max.


(B44) No. 15 — Body / 10 Ω, max.


(B44) No. 24 — Body / 10 Ω, max.

(B44) No. 25 — Body / 10 Ω, max.



C: IGNITION CONTROL SYSTEM






1. CHECK IGNITION SYSTEM FOR SPARKS.

- 1) Remove ignition coil from each spark plug.
- 2) Install new spark plug on ignition coil.

CAUTION:

Do not remove spark plug from engine.

- 3) Contact spark plug's thread portion on engine.
- 4) While opening throttle valve fully, crank engine to check that spark occurs at each cylinder.




2. CHECK POWER SUPPLY CIRCUIT FOR IGNITION COIL.

- 1) Turn ignition switch to OFF.
- 2) Disconnect connector from ignition coil.
- 3) Turn ignition switch to ON.
- 4) Measure power supply voltage between each ignition coil connector terminal and body.

Connector & terminal / Specified voltage:

(E21), (E19), (E22), (E20)

No. 1 — Body / 10 V, min.




3. CHECK IGNITION COIL.

- 1) Remove ignition coil.
- 2) Measure resistance between ignition coil terminals to check primary coil.

Terminals / Specified resistance:


No. 1 — No. 2 / 0.7 Ω



- 3) Measure resistance between spark plug contact portions to check secondary coil.

Connector & terminal / Specified resistance:

No. 1 — Contact portion / 13.8 kΩ



4. CHECK HARNESS CONNECTOR BETWEEN IGNITOR AND EACH IGNITION COIL.

- 1) Turn ignition switch to OFF.
- 2) Disconnect connector from ignitor.
- 3) Measure resistance of harness connector between each ignition coil and ignitor.


Connector & terminal / Specified resistance:

(B27) No. 1 — (E21) No. 2 / 10 Ω, max.

(B27) No. 3 — (E19) No. 2 / 10 Ω, max.

(B27) No. 2 — (E22) No. 2 / 10 Ω, max.

(B27) No. 4 — (E20) No. 2 / 10 Ω, max.



5. CHECK INPUT SIGNAL FOR IGNITOR.

Check if voltage varies synchronously with engine speed when cranking, while monitoring voltage between ignitor connector and body.


Connector & terminal / Specified voltage:

(B12) No. 1 — Body / 0.1 V, min. — 3.4 V, max.

(B12) No. 2 — Body / 0.1 V, min. — 3.4 V, max.

(B12) No. 3 — Body / 0.1 V, min. — 3.4 V, max.

(B12) No. 4 — Body / 0.1 V, min. — 3.4 V, max.



6. CHECK HARNESS CONNECTOR OF IGNITOR GROUND CIRCUIT.

- 1) Turn ignition switch to OFF.
- 2) Measure resistance between ignitor and body.

Connector & terminal / Specified resistance:

(B12) No. 5 — Body / 10 Ω, max.

7. CHECK HARNESS CONNECTOR BETWEEN ECM AND IGNITOR.

- 1) Disconnect connector from ECM.
- 2) Measure resistance of harness connector between ECM and ignitor.

Connector & terminal / Specified resistance:

- (B44) No. 7 — (B12) No. 1 / 10 Ω, max.
- (B44) No. 8 — (B12) No. 2 / 10 Ω, max.
- (B44) No. 9 — (B12) No. 3 / 10 Ω, max.
- (B44) No. 10 — (B12) No. 4 / 10 Ω, max.

- 3) Measure resistance of harness connector between ECM and body to make sure that circuit does not short.

Connector & terminal / Specified resistance:

- (B44) No. 7 — Body / 1 MΩ, min.
- (B44) No. 8 — Body / 1 MΩ, min.
- (B44) No. 9 — Body / 1 MΩ, min.
- (B44) No. 10 — Body / 1 MΩ, min.

