

## **DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)**

ENGINE (DIAGNOSTICS)

---

### **Y: DTC P0171 — FUEL TRIM MALFUNCTION (A/F TOO LEAN) —**

NOTE:

For the diagnostic procedure, refer to DTC P0172. <Ref. to EN(DOHC TURBO)-143, DTC P0172 — FUEL TRIM MALFUNCTION (A/F TOO RICH) —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

## Z: DTC P0172 — FUEL TRIM MALFUNCTION (A/F TOO RICH) —

- **DTC DETECTING CONDITION:**
  - Two consecutive driving cycles with fault
- **TROUBLE SYMPTOM:**
  - Erroneous idling
  - Engine stalls.
  - Poor driving performance

**CAUTION:**

After repair or replacement of faulty parts, conduct Clear Memory Mode<Ref. to EN(DOHC TURBO)-38, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(DOHC TURBO)-35, Inspection Mode.> .

Step	Check	Yes	No
1	<b>CHECK EXHAUST SYSTEM.</b>	Are there holes or loose bolts on exhaust system?	Repair exhaust system. Go to step 2.
2	<b>CHECK AIR INTAKE SYSTEM.</b>	Are there holes, loose bolts or disconnection of hose on air intake system?	Repair air intake system. Go to step 3.
3	<b>CHECK FUEL PRESSURE.</b> <b>Warning:</b> •Place “NO FIRE” signs near the working area. •Be careful not to spill fuel on the floor. 1)Release fuel pressure. (1) Disconnect connector from fuel pump relay. (2) Start the engine and run it until it stalls. (3) After the engine stalls, crank it for five more seconds. (4) Turn ignition switch to OFF. 2)Connect connector to fuel pump relay. 3)Disconnect fuel delivery hose from fuel filter, and connect fuel pressure gauge. 4)Install fuel filler cap. 5)Start the engine and idle while gear position is neutral. 6)Measure fuel pressure while disconnecting pressure regulator vacuum hose from intake manifold.  <b>Warning:</b> Before removing fuel pressure gauge, release fuel pressure.  <b>NOTE:</b> If fuel pressure does not increase, squeeze fuel return hose 2 to 3 times, then measure fuel pressure again.	Is fuel pressure between 284 and 314 kPa (2.9 — 3.2 kg/cm <sup>2</sup> , 41 — 46 psi)?	Go to step 4.  Repair the following items. <b>Fuel pressure too high</b> <ul style="list-style-type: none"> <li>• Clogged fuel return line or bent hose</li> </ul> <b>Fuel pressure too low</b> <ul style="list-style-type: none"> <li>• Improper fuel pump discharge</li> <li>• Clogged fuel supply line</li> </ul>

## DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

### ENGINE (DIAGNOSTICS)

Step	Check	Yes	No
<p><b>4</b></p> <p><b>CHECK FUEL PRESSURE.</b> After connecting pressure regulator vacuum hose, measure fuel pressure.</p> <p><b>Warning:</b> <b>Before removing fuel pressure gauge, release fuel pressure.</b></p> <p><b>NOTE:</b> •If fuel pressure does not increase, squeeze fuel return hose 2 to 3 times, then measure fuel pressure again. •If out of specification as measured at this step, check or replace pressure regulator and pressure regulator vacuum hose.</p>	<p>Is fuel pressure between 206 and 235 kPa (2.1 — 2.4 kg/cm<sup>2</sup>, 30 — 34 psi)?</p>	Go to step 5.	<p>Repair the following items.</p> <p><b>Fuel pressure too high</b></p> <ul style="list-style-type: none"> <li>• Faulty pressure regulator</li> <li>• Clogged fuel return line or bent hose</li> </ul> <p><b>Fuel pressure too low</b></p> <ul style="list-style-type: none"> <li>• Faulty pressure regulator</li> <li>• Improper fuel pump discharge</li> <li>• Clogged fuel supply line</li> </ul>
<p><b>5</b></p> <p><b>CHECK ENGINE COOLANT TEMPERATURE SENSOR.</b> 1)Start the engine and warm-up completely. 2)Read data of engine coolant temperature sensor signal using Subaru Select Monitor or OBD-II general scan tool.</p> <p><b>NOTE:</b> •Subaru Select Monitor For detailed operation procedure, refer to the "READ CURRENT DATA FOR ENGINE". &lt;Ref. to EN(DOHC TURBO)-28, Subaru Select Monitor.&gt; •OBD-II general scan tool For detailed operation procedures, refer to the OBD-II General Scan Tool Instruction Manual.</p>	<p>Is temperature greater than 60°C (140°F)?</p>	Go to step 6.	<p>Replace engine coolant temperature sensor. &lt;Ref. to FU(DOHC TURBO)-27, Engine Coolant Temperature Sensor.&gt;</p>
<p><b>6</b></p> <p><b>CHECK INTAKE MANIFOLD PRESSURE SENSOR.</b> 1)Start the engine and warm-up engine until coolant temperature is greater than 60°C (140°F). 2)Place the shift lever in neutral position. 3)Turn A/C switch to OFF. 4)Turn all accessory switches to OFF. 5)Read data of intake manifold pressure sensor signal using Subaru Select Monitor or OBD-II general scan tool.</p> <p><b>NOTE:</b> •Subaru Select Monitor For detailed operation procedure, refer to the "READ CURRENT DATA FOR ENGINE". &lt;Ref. to EN(DOHC TURBO)-28, Subaru Select Monitor.&gt; •OBD-II general scan tool For detailed operation procedure, refer to the OBD-II General Scan Tool Instruction Manual.</p> <p><b>Specification:</b> •Intake manifold absolute pressure</p> <p><b>Ignition ON</b> <b>73.3 — 106.6 kPa (550 — 800 mmHg, 21.65 — 31.50 inHg)</b></p> <p><b>Idling</b> <b>24.0 — 41.3 kPa (180 — 310 mmHg, 7.09 — 12.20 inHg)</b></p>	<p>Is the value within the specifications?</p>	Go to step 7.	<p>Replace mass air flow and intake manifold pressure sensor. &lt;Ref. to FU(DOHC TURBO)-32, Mass Air Flow and Intake Air Temperature Sensor.&gt;</p>

**DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)**  
ENGINE (DIAGNOSTICS)

	Step	Check	Yes	No
7	<p><b>CHECK INTAKE AIR TEMPERATURE SENSOR.</b></p> <p>1)Start the engine and warm-up engine until coolant temperature is greater than 60°C (140°F).</p> <p>2)Place the shift lever in neutral position.</p> <p>3)Turn A/C switch to OFF.</p> <p>4)Turn all accessory switches to OFF.</p> <p>5)Open front hood.</p> <p>6)Measure ambient temperature.</p> <p>7)Read data of intake manifold pressure sensor signal using Subaru Select Monitor or OBD-II general scan tool.</p> <p>NOTE:</p> <ul style="list-style-type: none"> <li>•Subaru Select Monitor</li> </ul> <p>For detailed operation procedure, refer to the "READ CURRENT DATA FOR ENGINE". &lt;Ref. to EN(DOHC TURBO)-28, Subaru Select Monitor.&gt;</p> <ul style="list-style-type: none"> <li>•OBD-II general scan tool</li> </ul> <p>For detailed operation procedure, refer to the OBD-II General Scan Tool Instruction Manual.</p>	<p>Is value obtained when ambient temperature is subtracted from intake air temperature greater than -10°C (14°F) and less than 50°C (122°F)?</p>	<p>Contact with your Subaru distributor service.</p> <p>NOTE: Inspection by DTM is required, because probable cause is deterioration of multiple parts.</p>	<p>Check mass air flow and intake air temperature sensor. &lt;Ref. to FU(DOHC TURBO)-32, Mass Air Flow and Intake Air Temperature Sensor.&gt;</p>

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)


## AB:DTC P0245 — WASTEGATE CONTROL SOLENOID VALVE CIRCUIT LOW INPUT —

- **DTC DETECTING CONDITION:**
  - Immediately at fault recognition
- **TROUBLE SYMPTOM:**
  - Erroneous idling

**CAUTION:**

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(DOHC TURBO)-38, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(DOHC TURBO)-35, Inspection Mode.> .

- **WIRING DIAGRAM:**



EN0974

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

Step	Check	Yes	No
<b>1 CHECK OUTPUT SIGNAL FROM ECM.</b> 1) Turn ignition switch to ON. 2) Measure voltage between ECM and chassis ground. <i>Connector &amp; terminal</i> <i>(B137) No. 24 (+) — Chassis ground (-):</i>	Is the voltage more than 10 V?	Even if MIL lights up, the circuit has returned to a normal condition at this time. Contact with your Subaru distributor.  NOTE: Inspection by DTM is required, because probable cause is deterioration of multiple parts.	Go to step 2.
<b>2 CHECK HARNESS BETWEEN WASTEGATE CONTROL SOLENOID VALVE AND ECM CONNECTOR.</b> 1) Turn ignition switch to OFF. 2) Disconnect connectors from wastegate control solenoid valve and ECM. 3) Measure resistance of harness between wastegate control solenoid valve connector and engine ground. <i>Connector &amp; terminal</i> <i>(B127) No. 1 — Engine ground:</i>	Is the resistance less than 10 $\Omega$ ?	Repair ground short circuit in harness between ECM and wastegate control solenoid valve connector.	Go to step 3.
<b>3 CHECK HARNESS BETWEEN WASTEGATE CONTROL SOLENOID VALVE AND ECM CONNECTOR.</b> Measure resistance of harness between ECM and wastegate control solenoid valve of harness connector. <i>Connector &amp; terminal</i> <i>(B137) No. 24 — (B127) No. 1:</i>	Is the resistance less than 1 $\Omega$ ?	Go to step 4.	Repair open circuit in harness between ECM and wastegate control solenoid valve connector.  NOTE: In this case, repair the following: • Open circuit in harness between ECM and wastegate control solenoid valve connector
<b>4 CHECK WASTEGATE CONTROL SOLENOID VALVE.</b> 1) Remove purge control solenoid valve. 2) Measure resistance between purge control solenoid valve terminals. <i>Terminals</i> <i>No. 1 — No. 2:</i>	Is the resistance between 30 and 34 $\Omega$ ?	Go to step 5.	Replace wastegate control solenoid valve. <Ref. to FU(DOHC TURBO)-40, Wastegate Control Solenoid Valve.>
<b>5 CHECK POWER SUPPLY TO WASTEGATE CONTROL SOLENOID VALVE.</b> 1) Turn ignition switch to ON. 2) Measure voltage between wastegate control solenoid valve and engine ground. <i>Connector &amp; terminal</i> <i>(B127) No. 2 (+) — Engine ground (-):</i>	Is the voltage more than 10 V?	Go to step 6.	Repair open circuit in harness between main relay and wastegate control solenoid valve connector.

## DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

### ENGINE (DIAGNOSTICS)

	Step	Check	Yes	No
6	<b>CHECK POOR CONTACT.</b> Check poor contact in wastegate control solenoid valve connector.	Is there poor contact in wastegate control solenoid valve connector?	Repair poor contact in wastegate control solenoid valve connector.	Contact with your Subaru distributor. NOTE: Inspection by DTM is required, because probable cause is deterioration of multiple parts.

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)


## AL:DTC P0340 — CAMSHAFT POSITION SENSOR CIRCUIT MALFUNCTION —

- **DTC DETECTING CONDITION:**
  - Immediately at fault recognition
- **TROUBLE SYMPTOM:**
  - Engine stalls.
  - Failure of engine to start

### CAUTION:

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(DOHC TURBO)-38, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(DOHC TURBO)-35, Inspection Mode.> .

- **WIRING DIAGRAM:**



EN0977

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

Step	Check	Yes	No
<b>1 CHECK HARNESS BETWEEN CAMSHAFT POSITION SENSOR AND ECM CONNECTOR.</b> 1) Turn ignition switch to OFF. 2) Disconnect connector from camshaft position sensor. 3) Measure resistance of harness between camshaft position sensor connector and engine ground. <b>Connector &amp; terminal</b> <b>(E15) No. 1 — Engine ground:</b>	Is the resistance more than 100 k $\Omega$ ?	Repair harness and connector.  NOTE: In this case, repair the following: <ul style="list-style-type: none"> <li>• Open circuit in harness between camshaft position sensor and ECM connector</li> <li>• Poor contact in ECM connector</li> <li>• Poor contact in coupling connector</li> </ul>	Go to step 2.
<b>2 CHECK HARNESS BETWEEN CAMSHAFT POSITION SENSOR AND ECM CONNECTOR.</b> Measure resistance of harness between camshaft position sensor connector and engine ground. <b>Connector &amp; terminal</b> <b>(E15) No. 1 — Engine ground:</b>	Is the resistance less than 10 $\Omega$ ?	Repair ground short circuit in harness between camshaft position sensor and ECM connector.  NOTE: The harness between both connectors are shielded. Repair ground short circuit in harness together with shield.	Go to step 3.
<b>3 CHECK HARNESS BETWEEN CAMSHAFT POSITION SENSOR AND ECM CONNECTOR.</b> Measure resistance of harness between camshaft position sensor connector and engine ground. <b>Connector &amp; terminal</b> <b>(E15) No. 2 — Engine ground:</b>	Is the resistance less than 5 $\Omega$ ?	Go to step 4.	Repair harness and connector.  NOTE: In this case, repair the following: <ul style="list-style-type: none"> <li>• Open circuit in harness between camshaft position sensor and ECM connector</li> <li>• Poor contact in ECM connector</li> <li>• Poor contact in coupling connector</li> </ul>
<b>4 CHECK CONDITION OF CAMSHAFT POSITION SENSOR.</b>	Is the camshaft position sensor installation bolt tightened securely?	Go to step 5.	Tighten camshaft position sensor installation bolt securely.
<b>5 CHECK CAMSHAFT POSITION SENSOR.</b> 1) Remove camshaft position sensor. 2) Measure resistance between connector terminals of camshaft position sensor. <b>Terminals</b> <b>No. 1 — No. 2:</b>	Is the resistance between 1 and 4 k $\Omega$ ?	Repair poor contact in camshaft position sensor connector.	Replace camshaft position sensor. <Ref. to FU(DOHC TURBO)-29, Camshaft Position Sensor.>

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)


## BC:DTC P0545 — EXHAUST GAS TEMPERATURE SENSOR CIRCUIT LOW INPUT —

- **DTC DETECTING CONDITION:**
  - Immediately at fault recognition
- **TROUBLE SYMPTOM:**
  - Hard to start
  - Erroneous idling
  - Poor driving performance

### CAUTION:

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(DOHC TURBO)-38, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(DOHC TURBO)-35, Inspection Mode.> .

### • WIRING DIAGRAM:



EN0984

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

Step	Check	Yes	No
<p><b>1</b></p> <p><b>CHECK CURRENT DATA.</b></p> <p>1)Start engine. 2)Read data of exhaust gas temperature sensor signal using Subaru Select Monitor or OBD-II general scan tool.</p> <p>NOTE: •Subaru Select Monitor For detailed operation procedure, refer to the "READ CURRENT DATA FOR ENGINE". &lt;Ref. to EN(DOHC TURBO)-28, Subaru Select Monitor.&gt; •OBD-II general scan tool For detailed operation procedures, refer to the OBD-II General Scan Tool Instruction Manual.</p>	<p>Is the value greater than 1200°C (2192°F)?</p>	<p>Go to step 2.</p>	<p>Repair poor contact.</p> <p>NOTE: In this case, repair the following:</p> <ul style="list-style-type: none"> <li>• Poor contact in exhaust gas temperature sensor</li> <li>• Poor contact in ECM</li> <li>• Poor contact in joint connector</li> </ul>
<p><b>2</b></p> <p><b>CHECK HARNESS BETWEEN EXHAUST GAS TEMPERATURE SENSOR AND ECM CONNECTOR.</b></p> <p>1)Turn ignition switch to OFF. 2)Disconnect connector from exhaust gas temperature sensor. 3)Turn ignition switch to ON. 4)Read data of exhaust gas temperature sensor signal using Subaru Select Monitor or OBD-II general scan tool.</p> <p>NOTE: •Subaru Select Monitor For detailed operation procedure, refer to the "READ CURRENT DATA FOR ENGINE". &lt;Ref. to EN(DOHC TURBO)-28, Subaru Select Monitor.&gt; •OBD-II general scan tool For detailed operation procedures, refer to the OBD-II General Scan Tool Instruction Manual.</p>	<p>Is the value less than 372°C (702°F)?</p>	<p>Replace exhaust gas temperature sensor. &lt;Ref. to FU(DOHC TURBO)-44, Exhaust Temperature Sensor.&gt;</p>	<p>Repair ground short circuit in harness between exhaust gas temperature sensor and ECM connector.</p>

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)


## BH: DTC P1088 — TUMBLE GENERATOR VALVE #1 (RH) POSITION SENSOR CIRCUIT LOW INPUT —

- **DTC DETECTING CONDITION:**
  - Immediately at fault recognition
- **TROUBLE SYMPTOM:**
  - Erroneous idling
  - Engine stalls.
  - Poor driving performance

**CAUTION:**

After repair or replacement of faulty parts, conduct Clear Memory Mode<Ref. to EN(DOHC TURBO)-38, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(DOHC TURBO)-35, Inspection Mode.> .


- **WIRING DIAGRAM:**
- **LHD MODEL**



# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

• RHD MODEL



EN0988

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

## ENGINE (DIAGNOSTICS)

Step	Check	Yes	No
<b>1 CHECK CURRENT DATA.</b> 1) Start engine. 2) Read data of tumble generator valve position sensor signal using Subaru Select Monitor or OBD-II general scan tool.  <b>NOTE:</b> • Subaru Select Monitor For detailed operation procedure, refer to the "READ CURRENT DATA FOR ENGINE". <Ref. to EN(DOHC TURBO)-28, Subaru Select Monitor.> • OBD-II general scan tool For detailed operation procedures, refer to the OBD-II General Scan Tool Instruction Manual.	Is the value less than 0.1 V?	Go to step 2.	Even if MIL lights up, the circuit has returned to a normal condition at this time. A temporary poor contact of the connector may be the cause.  <b>NOTE:</b> In this case, repair the following: • Poor contact in tumble generator valve position sensor connector • Poor contact in ECM connector • Poor contact in coupling connector
<b>2 CHECK INPUT SIGNAL FOR ECM.</b> Measure voltage between ECM connector and chassis ground while throttle valve is fully closed.  <b>Connector &amp; terminal</b> <b>(B135) No. 9 (+) — Chassis ground (-):</b>	Is the voltage more than 4.5 V?	Go to step 4.	Go to step 3.
<b>3 CHECK INPUT SIGNAL FOR ECM.</b> Measure voltage between ECM connector and chassis ground.  <b>Connector &amp; terminal</b> <b>(B135) No. 9 (+) — Chassis ground (-):</b>	Does the voltage change more than 4.5 V by shaking harness and connector of ECM while monitoring the value with voltage meter?	Repair poor contact in ECM connector.	Contact with your Subaru distributor service.  <b>NOTE:</b> Inspection by DTM is required, because probable cause is deterioration of multiple parts.
<b>4 CHECK INPUT SIGNAL FOR ECM.</b> Measure voltage between ECM connector and chassis ground.  <b>Connector &amp; terminal</b> <b>(B135) No. 23 (+) — Chassis ground (-):</b>	Is the voltage less than 0.1 V?	Go to step 6.	Go to step 5.
<b>5 CHECK INPUT SIGNAL FOR ECM. (USING SUBARU SELECT MONITOR.)</b> Measure voltage between ECM connector and chassis ground.	Does the voltage change more than 0.1 V by shaking harness and connector of ECM while monitoring the value with Subaru Select Monitor?	Repair poor contact in ECM connector.	Go to step 6.

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

Step	Check	Yes	No
<p><b>6</b></p> <p><b>CHECK HARNESS BETWEEN ECM AND TUMBLE GENERATOR VALVE POSITION SENSOR CONNECTOR.</b>                      1) Turn ignition switch to OFF.                      2) Disconnect connectors from throttle position sensor.                      3) Turn ignition switch to ON.                      4) Measure voltage between throttle position sensor connector and engine ground.  <b>Connector &amp; terminal</b>  <b>(E54) No. 1 (+) — Engine ground (-):</b></p>	<p>Is the voltage more than 4.5 V?</p>	<p>Go to step 7.</p>	<p>Repair harness and connector.                      NOTE:                      In this case, repair the following:</p> <ul style="list-style-type: none"> <li>• Open circuit in harness between tumble generator valve position sensor and ECM connector</li> <li>• Poor contact in throttle position sensor connector</li> <li>• Poor contact in ECM connector</li> <li>• Poor contact in coupling connector</li> <li>• Poor contact in joint connector</li> </ul>
<p><b>7</b></p> <p><b>CHECK HARNESS BETWEEN ECM AND TUMBLE GENERATOR VALVE POSITION SENSOR CONNECTOR.</b>                      1) Turn ignition switch to OFF.                      2) Measure resistance of harness between ECM connector and throttle position sensor connector.  <b>Connector &amp; terminal</b>  <b>(B135) No. 23 — (E54) No. 3:</b></p>	<p>Is the resistance less than 1 <math>\Omega</math>?</p>	<p>Go to step 8.</p>	<p>Repair harness and connector.                      NOTE:                      In this case, repair the following:</p> <ul style="list-style-type: none"> <li>• Open circuit in harness between tumble generator valve position sensor and ECM connector</li> <li>• Poor contact in ECM connector</li> <li>• Poor contact in tumble generator valve position sensor connector</li> <li>• Poor contact in coupling connector</li> </ul>
<p><b>8</b></p> <p><b>CHECK HARNESS BETWEEN ECM AND THROTTLE POSITION SENSOR CONNECTOR.</b>                      Measure resistance of harness between tumble generator valve position sensor connector and engine ground.  <b>Connector &amp; terminal</b>  <b>(E54) No. 3 — Engine ground:</b></p>	<p>Is the resistance less than 10 <math>\Omega</math>?</p>	<p>Repair ground short circuit in harness between tumble generator valve position sensor and ECM connector.</p>	<p>Go to step 9.</p>
<p><b>9</b></p> <p><b>CHECK POOR CONTACT.</b>                      Check poor contact in tumble generator valve position sensor connector.</p>	<p>Is there poor contact in tumble generator valve position sensor connector?</p>	<p>Repair poor contact in tumble generator valve position sensor connector.</p>	<p>Replace tumble generator valve assembly. &lt;Ref. to FU(DOHC TURBO)-38, Tumble Generator Valve Assembly.&gt;</p>

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC) ENGINE (DIAGNOSTICS)

## CH:DTC P1507 — IDLE CONTROL SYSTEM MALFUNCTION (FAIL-SAFE) —

**DTC DETECTING CONDITION:**

- Immediately at fault recognition


**TROUBLE SYMPTOM:**

- Engine keeps running at higher revolution than specified idling revolution.
- Fuel is cut according to fail-safe function.

**CAUTION:**

After repair or replacement of faulty parts, conduct Clear Memory Mode<Ref. to EN(DOHC TURBO)-38, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(DOHC TURBO)-35, Inspection Mode.> .

**WIRING DIAGRAM:**



# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

Step	Check	Yes	No	
<b>1</b>	<b>CHECK ANY OTHER DTC ON DISPLAY.</b>	Does the Subaru Select Monitor or OBD-II general scan tool indicate DTC P0506, P0507, P0508, P0509 or P1142?	Inspect DTC P0506, P0507, P0508, P0509 or P1142 using "17. List of Diagnostic Trouble Code (DTC)". <Ref. to EN(DOHC TURBO)-69, List of Diagnostic Trouble Code (DTC).>  NOTE: In this case, it is not necessary to inspect DTC P0507.	Go to step 2.
<b>2</b>	<b>CHECK AIR INTAKE SYSTEM.</b> 1)Turn ignition switch to ON. 2)Start engine, and idle it. 3)Check the following items. •Loose installation of intake manifold, idle air control solenoid valve and throttle body •Cracks of intake manifold gasket, idle air control solenoid valve gasket and throttle body gasket •Disconnections of vacuum hoses	Is there a fault in air intake system?	Repair air suction and leaks.	Go to step 3.
<b>3</b>	<b>CHECK THROTTLE CABLE.</b>	Does throttle cable have play for adjustment?	Go to step 4.	Adjust throttle cable. <Ref. to SP-9, INSTALLATION, Accelerator Control Cable.>
<b>4</b>	<b>CHECK AIR BY-PASS LINE.</b> 1)Turn ignition switch to OFF. 2)Remove idle air control solenoid valve from throttle body. <Ref. to FU(DOHC TURBO)-34, Idle Air Control Solenoid Valve.> 3)Confirm that there are no foreign particles in by-pass air line.	Are foreign particles in by-pass air line?	Remove foreign particles from by-pass air line.	Replace idle air control solenoid valve. <Ref. to FU(DOHC TURBO)-34, Idle Air Control Solenoid Valve.>