


## CROSS SECTIONAL VIEW

AUTOMATIC TRANSMISSION

### 2. Cross Sectional View



AT-02812

- |                                 |   |
|---------------------------------|---|
| (1) Torque converter assembly   | (10) Forward brake                      |
| (2) Input shaft                 | (11) Low coast brake                    |
| (3) Oil pump                    | (12) Reduction gear                     |
| (4) Front brake                 | (13) Variable torque distribution (VTD) |
| (5) Turbine speed sensor 1      | (14) Transfer clutch                    |
| (6) Input clutch                | (15) Rear vehicle speed sensor          |
| (7) Direct clutch               | (16) Rear drive shaft                   |
| (8) High and low reverse clutch | (17) Drive pinion shaft                 |
| (9) Reverse brake               | (18) Control valve                      |

**5AT-4**